

Stocking Parts: Gas Controls

| No. | Notes | MODEL GAS CODE | U98VA KE | U98VB KE | U98VB KL | | |
|-----|-------|--|--------------|--------------|--------------|--|--|
| 50 | Stk | Gas Valve - Natural Gas | 60-102787-04 | 60-102787-04 | 60-102787-04 | | |
| | Stk,2 | Gas Valve - LP | See Note 2 | See Note 2 | See Note 2 | | |
| 51 | Stk | Integrated Furnace Control Board (IFC) | 62-105563-04 | 62-105563-04 | 62-105563-05 | | |
| 52 | Stk | Flame Sensor | 62-23543-08 | 62-23543-08 | 62-23543-08 | | |
| 53 | Stk | Spark Ignitor | 62-24141-05 | 62-24141-05 | 62-24141-05 | | |
| | Stk | LP Conversion Kit - U.S./Canadian Models | FP-37 | FP-37 | FP-37 | | |