

INSTRUCTION SHEET FOR Turbo200[®] Mini

2.5 MFD Through 15.0 MFD Fan Motor-Run Capacitor Sizes

| EXAMPLE | MFD NEEDED | JUMPER WIRE(S) REQUIRED | FROM MOTOR TO CAPACITOR |
|---------------------------------------|--------------------------------------|--|--|
| <p>FROM MOTOR</p> | <p>5.0 MFD at 370/440VAC</p> | <p>NONE</p> <p>Total 5.0 MFD</p> | <p>Connect the wires from the motor as shown: one to the common (center) and one to the 5.0 MFD (white).</p> |
| <p>FROM MOTOR</p> | <p>7.5 MFD at 370/440VAC</p> | <p>NONE</p> <p>Total 7.5 MFD</p> | <p>Connect the wires from the motor as shown: one to the common (center) and one to the 7.5 MFD (brown).</p> |
| <p>FROM MOTOR</p> <p>Jumper Wire</p> | <p>10.0 MFD at 370/440VAC</p> | <p>YES (see example)</p> <p>Use one (1) yellow jumper wire and connect the 2.5 (green) terminal to the 7.5 (brown) terminal.</p> <p>Total 10.0 MFD</p> | <p>Connect the wires from the motor as shown: one to the common (center) and one to the 7.5 MFD (brown).</p> |
| <p>FROM MOTOR</p> <p>Jumper Wire</p> | <p>12.5 MFD at 370/440VAC</p> | <p>YES (see example)</p> <p>Use one (1) yellow jumper wire and connect the 5.0 (white) terminal to the 7.5 (brown) terminal.</p> <p>Total 12.5 MFD</p> | <p>Connect the wires from the motor as shown: one to the common (center) and one to the 7.5 MFD (brown).</p> |
| <p>FROM MOTOR</p> <p>Jumper Wires</p> | <p>15.0 MFD at 370/440VAC</p> | <p>YES (see example)</p> <p>Use two (2) yellow jumper wires for this value. [A] Connect the 2.5 (green) terminal to the 5.0 (white) terminal. [B] Connect the 5.0 (white) terminal to the 7.5 (brown) terminal.</p> <p>Total 15.0 MFD</p> | <p>Connect the wires from the motor as shown: one to the common (center) and one to the 7.5 MFD (brown).</p> |

Exclusive  Distributor
GLOBAL

For Technical Questions or Support
800-445-6033 / 386-445-6000

